

4. Remove screws and the seat storage tray



5. Position the seat cushion down.